

RED | GREY ANDERSON PLUG INSTALLATION



ESC | RED ANDERSON PLUG KIT



GREY ANDERSON PLUG KIT



Step 1:

Route cable toward rear of car from engine bay down along chassis rail toward rear, following existing wiring under car. **Be sure to avoid any hot or moving parts such as exhaust or drive shafts.** Use cable ties supplied in the kit to secure harness along route.

Once cable is routed to the rear of the vehicle it is time to mount the Anderson plug and cover near the existing trailer plug using the accessories supplied in the kit. Watch the following video to aid in this part of the installation.

[Link: Mounting Anderson Bracket](#)

Step 2:

Once you have mounted the Anderson plug on the rear of the car and secured the harness under the car its time to make the final electrical connections to the battery.

Connect the **red terminal** to the batteries **positive terminal** and the **black** cable to the batteries **negative terminal**. Now your Anderson installation is complete.